

Sensational effect:

Reverse decorative stitch embroidery!
The new Pfaff creative Bobbin Case accessory makes it possible.



Create beautiful bobbin work (also called reverse stitch embroidery) with the Pfaff creative Bobbin Case. Simple decorative stitches are given an entirely new look. The secret lies in the special bobbin hook and in the heavy threads that are wound on the bobbin. The reverse side of a decorative stitch becomes a unique embroidery. It's a great twist to give your favorite stitches a new look! It can be used on all Pfaff sewing machines*.

* Except hobby line.

Little purse – big impact!

Make an elegant purse for the evening, a fun accessory for daytime, or a cosmetic bag – it's up to you!

This elegant bag is a real gem. It may look complicated, but it's really quite easy to make. Does your sewing machine have decorative stitches? Then we have something special for you! With the newest accessory from Pfaff, the creative Bobbin Case, you can turn a simple decorative stitch into a unique little embroidery with a 3D effect. Have fun with it! You can find more interesting projects to make yourself at www.pfaff.com.

Fancy evening purse

Size 14 x 23 cm (5 1/2" x 9")

Supplies:

- Pink silk fabric 50 x 90 cm (20" x 35 1/2")
- Pink organza fabric 30 x 45 cm (11 3/4" x 17 3/4")
- Sulky Ultra Stable 25 x 40 cm (10 x 16") (Article No: 620 003-796)
- Pink sewing thread
- Embroidery thread in light pink and dark pink
- Decorative thick threads for bobbin work
- 4 mm/6 mm light pink bead string 100 cm (39")
- 6 mm pink silk ribbon 100 cm (39")
- 10 mm pink silk ribbon 50 cm (19 3/4")
- Pfaff fabric marking pen (Article No: 412 752-501)
- 1 magnetic closure
- Pfaff creative Bobbin Case (Article No: 820 602-096)
- Beading Foot 4 mm (Article No: 820 604-096)
- Beading Foot 6 mm (Article No: 820 605-096)
- Decorative Trim Foot (Article No: 820 614-096)

1 Cutting Instruction

1 cm (3/8") seam allowance is included.

Pink Silk fabric

- 2 pc – 25 x 40 cm (10" x 16")
- 2 pc – 7.5 x 25 cm (3" x 10")

Pink Organza fabric

- 1 pc – 25 x 40 cm (10" x 16")

Sulky Ultra Stable

- 1 pc – 25 x 40 cm (10" x 16")

Press the Sulky Ultra Stable stabilizer onto the wrong side of the 25 x 40 cm (10" x 16") pink silk fabric. Mark the center line with the water soluble fabric pen. Lay the 25 x 40 cm (10" x 16") organza fabric over the pink silk fabric and baste it in place.



2 Pfaff creative Bobbin Case

Create beautiful bobbin work, also called reverse decorative stitch embroidery, with the Pfaff creative Bobbin Case. There are different ways to use the Pfaff creative Bobbin Case, depending on the type of decorative thread you are using, so be sure to use the correct method for your project.

For heavy or specialty threads:

Wind the bobbin with the decorative thread slowly. For less texture, use finer specialty threads. Put the bobbin in the creative Bobbin Case, pull the specialty thread into the bobbin tension and adjust the bobbin tension screw, so the thread pulls evenly and has a slight tension.

For heavier yarns and textured specialty threads:

Wind the bobbin evenly clockwise by hand. Put the bobbin in the bobbin case. For most textured bobbin work, do not pull the heavy thread or yarn into the bobbin tension, but go directly into the bypass slot. To bring up the bobbin thread, hold the needle thread and turn the hand wheel towards you.

- n Thread your Pfaff sewing machine with regular sewing thread. Use the recommended size needle for your fabric. Snap on the presser foot 2/2A or 8.
- n Place the organza side of the fabric face down with the stabilizer facing up. Select stitches with a loose density, and experiment with straight, zigzag and decorative stitches. Increase the stitch length for best results.
- n Select slow speed and stitch at an even speed. Increase needle thread tension slightly if needed.

Before sewing on your project, practice on a scrap of fabric until your adjustments are set.

3 Beading feet

Embellish your project with beautiful beads by using the 4 mm or 6 mm Pfaff beading feet. These two feet will easily guide the bead string through a groove so that your Pfaff sewing machine can invisibly stitch your beads in place.

- n Snap on the 4 mm or 6 mm Beading Foot. Thread your machine with invisible thread in the needle and regular sewing thread that matches the fabric in the bobbin.

- n Select a zigzag stitch or a blindhem stitch and adjust the settings of the stitch according to the size of the beads.

Zigzag stitch:

- For 4 mm beads: length 3 - 4/width 4
- For 6 mm beads: length 6/width 6

Blindhem stitch:

- For 4 mm beads: length 1/width 4.5
- For 6 mm beads: length 1.5/width 6

4 Decorative Trim Foot

Embellish your project with different types of trims by using the Decorative Trim Foot. This foot will easily guide the trims through the opening at the front and through the groove under the presser foot.

The presser foot has two openings and one small groove. The first opening is perfect for 6 mm (1/4") wide trims, the second opening is for 12 mm (1/2") wide trims. The groove that is just in front of the needle is for 3 mm (1/8") wide trims.

- n Thread your machine with a regular sewing thread or decorative thread on top and regular sewing thread in the bobbin.

- n Select a straight, zigzag or decorative stitch. Avoid using stitches with side motion or stitches with too much motion forward and back.

Tip:

For the 6 mm wide trims, you can also use a 6 mm twin needle. Select a straight stitch and it will sew at the edges of the trim.

- n Place the trim in the presser foot.
- n Snap on the Decorative Trim Foot.
- n Engage the IDT™.
- n Sew slowly and carefully. Engage the sew slow function if your machine has it.

5 Sewing

- n Place the embellished piece and the silk lining on top of each other, right sides together. Thread your Pfaff sewing machine with matching sewing thread on top and bottom. Sew a straight stitch along the edges with a 1 cm (3/8") seam allowance and leave an opening, for turning right side out. Be very careful when stitching close to the beads, as you might need to lift your presser foot up and start over again after the beads.

- n Trim seam allowances and corners. Turn right side out. Press.

- n Topstitch along the edges. This will also close the opening.

Side pieces

- n Fold in half right sides together. Stitch along the long sides with a straight stitch. Turn right side out. (Ill. 1)
- n Turn under the raw edges on the bottom. Fold the side piece in half lengthwise and sew a straight stitch across the opening. (Ill. 2)
- n Place the side piece along the edge of the purse with the bottom straight stitch seam facing the fold of the purse. (Ill. 3)
- n Line up the edge of the side piece with the edge of the purse. Sew the side piece to the purse lengthwise, so you get the beginning of the fold at the opening of the purse. Do the same with the other side piece. (Ill. 3)
- n Place a magnetic closure or a button to close your evening purse.

